iSmart mrHandsfree

User's Manual

GB NL F D I ES
DK EST RU CZ SK



DECLARATION OF CONFORMITY

We, the undersigned,

Company:	TE-GROUP nv
Address:	Kapelsestraat 61, 2950 Kapellen - BELGIUM

declare, that the following equipment:

Product Name:	mr Handsfree iSmart
Product Type:	Bluetooth® Speakerphone

Conforms with the requirements of European Council Directive 99/5/EC.

CE

GB

INSTALLATION
See illustration I

The ISMART can be installed in your car using either one of the 2 mounting accessories:

A. Ventilator mount
The ISMART ventilator mount is designed to suit most car ventilation grilles. Fix the 2 legs of the ventilation mount onto the big plate. Afterwards, fix the 2 legs onto your car ventilation grille. Adjust the ventilator mount and ventilation grille in the best possible position for the carkit. Make sure that the location and fixation cannot influence the safety of driving. After that, connect the ISMART cradle to the ventilator mount.

B. Suction cup
Mount the suction cup onto the windshield and press the button firmly to secure it in place. Adjust the holder in the good position and make sure that it cannot influence the safety of driving. Then connect the ISMART cradle to the suction cup. Connect the USB cable to the ISMART and the cigarette plug to charge the battery of the carkit. It will also charge your iPhone as soon as it is placed in the cradle.

PARTS & FUNCTIONS
See illustration II

1. Charging connector

2. Latch to fix the iPhone in the holder

3. USB charging socket (Charging the battery)
The ISMART offers 2 charging options:
A. USB cable (11)
B. Cigarette lighter (10)
Make sure that the ISMART is fully charged before using the device.

4. Phone button (Turning on / Turning off / Pairing / answer/end/reject a call / Voice dialing / Redial / 2nd call)

- **Turning ON / OFF automatically (by motion sensor)):**
When using the ISMART for the first time, you ALWAYS have to use the Phone button (4) for powering ON the unit and start pairing procedure. The ISMART is provided with a motion sensor . The ISMART turns ON and connects automatically with the last connected phone the moment you enter the car! You will also hear the connection beep tone. The ISMART will also turn OFF automatically after you have left the car.
In the following cases we advise you to turn the ISMART OFF manually (by pressing the Phone button(4)) :
• When driving with the ISMART and no Bluetooth® connection with your phone
• When hand carrying without using (e.g. when travelling in luggage, ...)
- **Turning ON / OFF manually (by pressing Phone button (4)):**
• Turning ON: Press the Phone button (4) until you hear a beep tone and the blue LED indicator (5) starts flashing.
• Turning off: Press the Phone button (4) until you hear a beep tone and the red LED indicator (5) lights up briefly before turning OFF again.
NOTE:
After entering the Bluetooth® range of your carkit or when the carkit just turned ON by motion sensor, automatic reconnection sometimes can take more than 10 seconds.
Attention!
The ISMART will also turn off automatically if there has been no Bluetooth® connection between the ISMART and another mobile device for more than 10 minutes.
- **Pairing:**
First use pairing: When the ISMART is turned on for the first time, it will automatically enter pairing mode and search for available Bluetooth® devices (the LED indicator (5) starts flashing by blue and red colors alternately). → Let your phone search for Bluetooth® devices. → Confirm the connection with the ISMART in the menu of your mobile phone and enter the PIN code 0000* to pair both devices. You will hear a long beep. → The blue LED indicator (5) will start flashing again. **PIN code is usually not required for Bluetooth® 2.1 (or higher) mobile phones*
Normal pairing: Make sure that the ISMART is turned off. → Press and hold the Phone button (4) until the LED indicator (5) starts flashing by blue and red colors alternately. → Let your phone search for Bluetooth® devices. → Select the ISMART in your mobile phone and enter the PIN code 0000* to pair both devices. You will hear a long beep. → The blue LED indicator (5) will start flashing again.**PIN code is usually not required for Bluetooth® 2.1 (or higher) mobile phones/*
Attention!
• To ensure automatic reconnection between the phone and the ISMART, we recommend setting the ISMART as "Authorized" in the Bluetooth® menu of your phone! Please refer to the manual of your mobile phone for more detailed information.
• If the Bluetooth® connection is not restored automatically after disconnection, press the Phone button (4) to restore the connection manually.
- **Answer / end / reject a call:**
- Incoming call: Press 1x to answer a call.
- Incoming call: Press and hold (3 sec.) to reject a call.
- During a conversation: Press 1x to end a call.
- Standby mode: Press 1x to restore the Bluetooth® connection after it has been broken.
- **Voice dialing / redial / 2nd call:**
- Standby mode: Press 1x to activate voice dialing.
Attention!
The voice dialing function is only available if it is supported by your mobile phone!
- Standby mode: Press quickly 2x to redial the last dialed number.
- During a conversation: Press 2x when you hear a beep (2nd call) to answer a 2nd call and put the current call on hold.
- During a conversation: Press briefly 2x to switch between 2 calls.
- During 2nd call: Press 1x to end 1 of the 2 calls.
Attention!
Some phones do not support this Bluetooth® function or need confirmation through the mobile phone menu!

5. LED indicator
- **Red indicator:**
• Flashes in Standby mode: low battery capacity.
• Lights continuously while charging the battery.
• Lights continuously in mute mode.
- **Blue indicator:**
• Flashes in Standby mode.
- **Red & Blue indicators:**
• Flash alternately in pairing mode.

6. Microphone
Make sure that the microphone is directed towards your mouth. For optimum performance, the microphone should be located at a distance of 60 cm from the drivers' mouth. Make sure that there are no obstacles in front of the microphone of the ISMART.

7. Speaker

8. (+) and (-) Volume buttons (adjust the volume / switching calls from ISMART to mobile phone and back)
- **Adjust the volume:**
- Press (+) to increase the volume level.
- Press (-) to decrease the volume level.
The volume for iPhone 4 / 4S is usually 60 ~ 70 %, for iPhone 3GS close to 100 % and for iPhone 3G about 80 %.
- **Switching calls from ISMART to mobile phone:** During a conversation, press the Volume + and Volume – button simultaneously. This will only work during a single call. If you press again shortly simultaneously the Volume + and Volume – button, the call is transferred back to the carkit.

9. Mute-button (M)
- Turn on mute mode: During a conversation, press the M button (9) to temporarily turn off the microphone of the ISMART. You will hear a tone signal every 30 seconds.
- Turn off mute mode: Press the M button (9) again to activate the microphone again.

10. Car charger

11. USB charging cable

12. 3,5 mm jack cable
You can use the 3,5 mm jack cable to connect the ISMART to the car radio system to transfer the sound over the speakers of your car.

Note:
The ISMART is suitable for both handsfree calling and music listening. It is provided with different Bluetooth® profiles to support this feature. This enables your navigation application (if you have this installed on your iPhone) to transfer the sound of the guidance instructions over the carkit speaker.

GUARANTEE
Mr Handsfree is a registered trademark of TE-Group NV. The mr Handsfree brand stands for superior product quality and outstanding customer service. That is why mr Handsfree warrants this product against all defects in material and workmanship for a period of **two (2) years** from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of mr Handsfree under this guarantee can be downloaded from our website: www.mrhandsfree.com.